

Order No.	Description
6ES7120-0AH00-0AA0	SIMATIC SC, TERMINALBLOCK TB16SC
6ES7120-0AH01-0AA0	SIMATIC SC, TERMINALBLOCK TB16SC
6ES7120-0AH50-0AA0	SIMATIC SC, TERMINALBLOCK
6ES7120-0BH01-0AA0	SIMATIC SC, TERMINALBLOCK TB16SC
6ES7120-0BH50-0AA0	SIMATIC SC, TERMINALBLOCK
6ES7120-1AH00-0AA0	SIMATIC SC, ZUSATZKLEMME
6ES7120-1BH00-0AA0	SIMATIC SC, ZUSATZKLEMME
6ES7120-2AH00-0AA0	SIMATIC SC, ZUSATZKLEMME
6ES7120-2BH00-0AA0	SIMATIC SC, ZUSATZKLEMME
6ES7121-1BB00-0AA0	SIMATIC SC, ELEKTRONIKMODULE
6ES7121-1FA00-0AA0	SIMATIC SC, ELEKTRONIKMODUL
6ES7122-1BB00-0AA0	SIMATIC SC, ELEKTRONIKMODULE
6ES7122-1BB10-0AA0	SIMATIC SC, ELEKTRONIKMODUL
6ES7122-1FA00-0AA0	SIMATIC SC, ELEKTRONIKMODUL
6ES7122-1HA01-0AA0	SIMATIC SC, ELEKTRONIKMODUL
6ES7123-1FB00-0AB0	SIMATIC SC, ELEKTRONIKMODUL
6ES7123-1FB50-0AB0	SIMATIC SC, ELEKTRONIKMODUL
6ES7123-1GB00-0AB0	SIMATIC SC, ELEKTRONIKMODUL
6ES7123-1GB10-0AB0	SIMATIC SC, ELEKTRONIKMODUL
6ES7123-1GB50-0AB0	SIMATIC SC, ELEKTRONIKMODUL
6ES7123-1GB60-0AB0	SIMATIC SC, ELEKTRONIKMODUL
6ES7123-1JA00-0AB0	SIMATIC SC, ELEKTRONIKMODUL
6ES7123-1JB00-0AB0	SIMATIC SC, ELEKTRONIKMODUL
6ES7124-1FA00-0AB0	SIMATIC SC, ELEKTRONIKMODUL
6ES7124-1GA00-0AB0	SIMATIC SC, ELEKTRONIKMODUL
6ES7127-1BE00-0AB0	SIMATIC SC, ELEKTRONIKMODUL
6ES7131-0BH00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7131-0BL00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7131-0BL10-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7131-0HF00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7131-1BH00-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7131-1BH01-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7131-1BH10-0XB0	SIMATIC S7, ELEKTRONIKBLOCK
6ES7131-1BH11-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7131-1BH12-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7131-1BL00-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7131-1BL01-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7131-1BL11-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7131-1BL12-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7131-1EH00-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7131-4BB00-0AA0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7131-4BB00-0AB0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7131-4BD00-0AA0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7131-4BD00-0AB0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7131-4BD50-0AA0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7131-4CD00-0AB0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7131-4EB00-0AB0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7131-4FB00-0AB0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7131-4RD00-0AB0	SIMATIC DP, 1 ELEKTRONIKMODUL
6ES7131-5RD00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7132-0BH00-0XB0	SIMATIC DP, ELEKTRONIKMODUL

Order No.	Description
6ES7132-0BH01-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7132-0BH10-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7132-0BH11-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7132-0BL00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7132-0BL01-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7132-0GF00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7132-0HF00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7132-0HH00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7132-0HH01-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7132-1BH00-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7132-1BH10-0XB0	SIMATIC S7, ELEKTRONIKBLOCK
6ES7132-1BH11-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7132-1BL00-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7132-1EH00-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7132-1JH00-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7132-4BB00-0AA0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7132-4BB00-0AB0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7132-4BB30-0AA0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7132-4BB30-0AB0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7132-4BD00-0AA0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7132-4BD30-0AA0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7132-4FB00-0AB0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7132-4HB00-0AB0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7132-4HB10-0AB0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7132-5SB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7133-0BH00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7133-0BH01-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7133-0BH10-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7133-0BL00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7133-0BN00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7133-0BN01-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7133-0BN10-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7133-0BN11-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7133-0HH00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7133-0HH01-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7133-1BL00-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7133-1BL01-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7133-1BL10-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7133-1BL11-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7133-1EH00-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7133-1JH00-0XB0	SIMATIC DP, ELEKTRONIKBLOCK
6ES7134-0HF00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-0HF01-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-0KH00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-0KH01-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4FB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4FB50-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4FB51-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4GB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4GB10-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4GB50-0AB0	SIMATIC DP, ELEKTRONIKMODUL

Order No.	Description
6ES7134-4GB51-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4GB60-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4GB61-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4JB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4JB50-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4LB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4MB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4NB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-4NB50-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-5RB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-5RB50-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-5SB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-5SB50-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-5TB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7134-5TB50-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7135-0HF00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7135-0HF01-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7135-4FB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7135-4GB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7135-4LB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7135-4LB01-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7135-4MB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7135-4MB01-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7135-5RB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7135-5TB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-1XL00-0XB0	SIMATIC SC, ANSCHALTUNG IM-SC
6ES7138-4AA00-0AA0	SIMATIC DP, 5 RESERVEMODULE
6ES7138-4AA10-0AA0	SIMATIC DP, 1 RESERVEMODUL
6ES7138-4CA00-0AA0	SIMATIC DP, POWERMODUL PM-E
6ES7138-4CA50-0AB0	SIMATIC DP, POWERMODUL PM-E
6ES7138-4CB00-0AB0	SIMATIC DP, POWERMODUL PM-E
6ES7138-4CB10-0AB0	SIMATIC DP, POWERMODUL PM-E
6ES7138-4CF00-0AB0	SIMATIC DP, POWERMODUL PM-E F
6ES7138-4CF01-0AB0	SIMATIC DP, POWERMODUL PM-E F
6ES7138-4CF40-0AB0	SIMATIC DP, POWERMODUL PM-E F
6ES7138-4DA00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DA01-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DA02-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DA03-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DB01-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DC00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DD00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DE00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DE01-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DF00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DF10-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DG00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DH00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DJ00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4DK00-0AB0	SIMATIC DP, ELEKTRONIKMODUL

Order No.	Description
6ES7138-4FA00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4FA01-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4FB00-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4FB01-0AB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7138-4GA00-0AB0	SIMATIC DP, 5 ELEKTRONIKMODULE
6ES7138-4HA00-0AB0	SIMATIC DP, DP-MASTERANSCHALT.
6ES7138-5EA00-0AA0	SIMATIC DP,
6ES7141-0BF00-0XB0	SIMATIC S5/S7, ET 200C
6ES7141-1BD30-0XA0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7141-1BD31-0XA0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7141-1BF00-0AB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7141-1BF00-0XB0	SIMATIC S5/S7,BASISMODUL BM 141
6ES7141-1BF01-0AB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7141-1BF01-0XB0	SIMATIC DP, BASISMODUL BM 141
6ES7141-1BF01-1XB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7141-1BF10-0XB0	SIMATIC DP, BASISMODUL BM 141
6ES7141-1BF10-1XB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7141-1BF11-0XB0	SIMATIC DP, BASISMODUL BM 141
6ES7141-1BF12-0XB0	SIMATIC DP, BASISMODUL BM 141
6ES7141-1BF30-0XA0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7141-1BF30-0XB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7141-1BF31-0XA0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7141-1BF40-0AB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7141-1BF40-0XA0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7141-1BF40-0XB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7141-1BF41-0XA0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7141-3BF00-0XA0	SIMATIC DP, GRUNDMODUL BM 141
6ES7141-3BH00-0XA0	SIMATIC DP, GRUNDMODUL BM 141
6ES7142-0BF00-0XB0	SIMATIC S5/S7, ET 200C
6ES7142-0BF01-0XB0	SIMATIC S5/S7, ET 200C
6ES7142-0BF10-0XB0	SIMATIC S5/S7, ET 200C
6ES7142-0BF11-0XB0	SIMATIC S5/S7, ET 200C
6ES7142-1BD10-0XB0	SIMATIC S5/S7,BASISMODUL BM 142
6ES7142-1BD11-0XB0	SIMATIC DP, BASISMODUL BM 142
6ES7142-1BD11-1XB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7142-1BD20-0XB0	SIMATIC DP, BASISMODUL BM 142
6ES7142-1BD20-1XB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7142-1BD21-0XB0	SIMATIC DP, BASISMODUL BM 142
6ES7142-1BD22-0XB0	SIMATIC DP, BASISMODUL BM 142
6ES7142-1BD30-0XA0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7142-1BD40-0XA0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7142-1BD40-0XB0	SIMATIC DP,ERWEITERUNGSMODUL
6ES7142-1BF30-0XA0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7142-3BF00-0XA0	SIMATIC DP, GRUNDMODUL BM 142
6ES7142-3BH00-0XA0	SIMATIC DP, GRUNDMODUL BM 142
6ES7143-0BL00-0XB0	SIMATIC S5/S7, ET 200C
6ES7143-0BL10-0XB0	SIMATIC S5/S7, ET 200C
6ES7143-1BF00-0AB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7143-1BF00-0XB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7143-1BF30-0XB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7143-2BH00-0AB0	SIMATIC DP, DEZENTR. PERIPHERIE

Order No.	Description
6ES7143-2BH50-0AB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7143-3BH00-0XA0	SIMATIC DP, GRUNDMODUL BM 143
6ES7143-3BH10-0XA0	SIMATIC DP, GRUNDMODUL BM 143
6ES7144-0HF00-0XB0	SIMATIC S5/S7, ET 200C
6ES7144-0KH00-0XB0	SIMATIC S5/S7, ET 200C
6ES7144-1FB30-0XB0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7144-1FB31-0XB0	SIMATIC DP,ERWEITERUNGSMODUL
6ES7144-1GB31-0XB0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7144-1GB40-0XB0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7144-1GB41-0XB0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7144-1JB30-0XB0	SIMATIC S5/S7,ERWEITERUNGSMODUL
6ES7144-1JB31-0XB0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7145-0HF00-0XB0	SIMATIC S5/S7, ET 200C
6ES7145-1FB31-0XB0	SIMATIC DP, ERWEITERUNGSMODUL
6ES7145-1GB31-0XB0	SIMATIC DP,ERWEITERUNGSMODUL
6ES7147-1AA00-0XB0	SIMATIC S5/S7, BASISMODUL
6ES7147-1AA01-0XB0	SIMATIC DP, BASISMODUL
6ES7147-1AA10-0XB0	SIMATIC DP, BASISMODUL
6ES7147-2AA00-0XB0	SIMATIC DP, BASISMODUL
6ES7148-1CA00-0XB0	SIMATIC DP, POWERMODUL
6ES7148-1DA00-0XA0	SIMATIC DP, PNEUMATIC-MODUL
6ES7148-1EH00-0XA0	SIMATIC DP, PNEUMATIC-INTERFACE
6ES7148-1EH01-0XA0	SIMATIC DP, PNEUMATIC-INTERFACE
6ES7148-1EH10-0XA0	SIMATIC DP, PNEUMATIC-INTERFACE
6ES7148-1EH11-0XA0	SIMATIC DP, PNEUMATIC-INTERFACE
6ES7148-1FA00-0XB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7148-1FA10-0XB0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7148-3FA00-0XB0	SIMATIC DP, ELEKTRONIKMODUL
6ES7151-1AA00-0AB0	SIMATIC DP, INTERFACEMODUL
6ES7151-1AA01-0AB0	SIMATIC DP, INTERFACEMODUL
6ES7151-1AA02-0AB0	SIMATIC DP, INTERFACEMODUL
6ES7151-1AA02-4AB2	SIMATIC DP, INTERFACEMODUL
6ES7151-1AA03-0AB0	SIMATIC DP, INTERFACEMODUL
6ES7151-1AB00-0AB0	SIMATIC DP, INTERFACEMODUL
6ES7151-1AB01-0AB0	SIMATIC DP, INTERFACEMODUL
6ES7151-1AB02-0AB0	SIMATIC DP, INTERFACEMODUL
6ES7151-1BA00-0AB0	SIMATIC DP, INTERFACEMODUL
6ES7151-1CA00-0AB0	SIMATIC DP, INTERFACEMODUL
6ES7151-2AA00-0AB0	SIMATIC DP, INTERFACEMODUL
6ES7151-3AA00-0AB0	SIMATIC DP, INTERFACEMODUL
6ES7151-7AA00-0AB0	SIMATIC DP, IM151-7 CPU FUER
6ES7151-7AA00-4AB2	SIMATIC DP, IM151-7 CPU FUER
6ES7151-7AA10-0AB0	SIMATIC DP, IM151-7 CPU FUER
6ES7151-7AB00-0AB0	SIMATIC DP, IM151-7 CPU FO FUER
6ES7151-7FA00-0AB0	SIMATIC DP, IM151-7 F-CPU FUER
6ES7153-1AA00-0XB0	SIMATIC S7-300, ET 200M
6ES7153-1AA01-0XB0	SIMATIC S7-300, ET 200M
6ES7153-1AA02-0XB0	SIMATIC S7-300, ET 200M
6ES7153-1AA03-0XB0	SIMATIC DP, ET 200M
6ES7153-1AA82-0XB0	SIMATIC DP, ANSCHALTUNG ET200 M
6ES7153-1AA83-0XB0	SIMATIC DP, ANSCHALTUNG ET200 M

Order No.	Description
6ES7153-2AA00-0XB0	SIMATIC S7-300, ET 200M
6ES7153-2AA01-0XB0	SIMATIC S7-300, ET 200M
6ES7153-2AA02-0XB0	SIMATIC DP, ANSCHALTUNG ET 200M
6ES7153-2AB00-0XB0	SIMATIC S7-300, ET 200M
6ES7153-2AB01-0XB0	SIMATIC DP, ANSCHALTUNG ET 200M
6ES7153-2BA00-0XB0	SIMATIC DP, ANSCHALTUNG ET 200M
6ES7153-2BB00-0XB0	SIMATIC DP, ANSCHALTUNG ET 200M
6ES7153-3AA00-0XB0	SIMATIC S7-300, ET 200M
6ES7153-3AA01-0XB0	SIMATIC S7-300, ET 200M
6ES7156-0AA00-0XA0	SIMATIC S5/S7, FELDBUSKOPPLER
6ES7156-0AA01-0XA0	SIMATIC DP, FELDBUSKOPPLER
6ES7158-0AA00-0XA0	SIMATIC S5/S7, DEZ. PERIPHERIE
6ES7158-0AA01-0XA0	SIMATIC DP, DEZ. PERIPHERIE
6ES7158-0AC00-0XA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7158-0AD00-0XA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7158-0AD01-0XA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7178-4BH00-0AE0	SIMATIC S7-300, INTERFACE MODUL
6ES7180-0AA00-0XA0	SIMATIC DP, MASTERMODUL IM180
6ES7181-0AA00-0AA0	SIMATIC DP, TESTGERAET BT200
6ES7181-0AA00-0XA0	SIMATIC S5/S7, IM 181
6ES7181-0AA01-0AA0	SIMATIC DP, BUSTESTER BT200
6ES7181-0AA01-0XA0	SIMATIC DP, IM 181
6ES7182-0AA00-0XA0	SIMATIC S5/S7, IM 182
6ES7182-0AA01-0XA0	SIMATIC DP, IM 182-1
6ES7183-0AA01-0XA0	SIMATIC DP, SLAVEMODUL
6ES7184-0AA00-0XA0	SIMATIC DP, SLAVEMODUL IM 184
6ES7192-0AA00-0AA0	SIMATIC SC, SCHIRMANSCHLUSSKL.
6ES7193-0CA10-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-0CA20-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-0CA30-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-0CA40-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-0CB10-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-0CB20-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-0CB30-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-0CB40-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-0CC10-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-0CD40-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-0CE30-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-0DA00-0XA0	SIMATIC DP, SICHERUNGEN
6ES7193-0DB00-0XA0	SIMATIC DP, SICHERUNGEN
6ES7193-0DC00-0XA0	SIMATIC DP, SICHERUNGEN
6ES7193-1CH00-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-1CH10-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-1CH20-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-1CL00-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-1CL10-0XA0	SIMATIC DP, TERMINALBLOCK
6ES7193-1FH20-0XA0	SIMATIC DP, ZUSATZKLEMME
6ES7193-1FH30-0XA0	SIMATIC DP, ZUSATZKLEMME
6ES7193-1FH50-0XA0	SIMATIC DP, ZUSATZKLEMME
6ES7193-1FH60-0XA0	SIMATIC DP, ZUSATZKLEMME
6ES7193-1FL20-0XA0	SIMATIC DP, ZUSATZKLEMME

Order No.	Description
6ES7193-1FL30-0XA0	SIMATIC DP, ZUSATZKLEMME
6ES7193-1FL50-0XA0	SIMATIC DP, ZUSATZKLEMME
6ES7193-1FL60-0XA0	SIMATIC DP, ZUSATZKLEMME
6ES7193-4CA20-0AA0	SIMATIC DP, 5 TERMINALMODULE
6ES7193-4CA30-0AA0	SIMATIC DP, 5 TERMINALMODULE
6ES7193-4CA40-0AA0	SIMATIC DP,
6ES7193-4CA50-0AA0	SIMATIC DP,
6ES7193-4CA70-0AA0	SIMATIC DP, 5 TERMINALMODULE
6ES7193-4CA80-0AA0	SIMATIC DP,
6ES7193-4CB00-0AA0	SIMATIC DP, 5 TERMINALMODULE
6ES7193-4CB10-0AA0	SIMATIC DP, 5 TERMINALMODULE
6ES7193-4CB20-0AA0	SIMATIC DP, 5 TERMINALMODULE
6ES7193-4CB30-0AA0	SIMATIC DP, 5 TERMINALMODULE
6ES7193-4CB60-0AA0	SIMATIC DP, 5 TERMINALMODULE
6ES7193-4CB70-0AA0	SIMATIC DP, 5 TERMINALMODULE
6ES7193-4CC20-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CC30-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CC70-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CD20-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CD30-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CD70-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CE00-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CE10-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CE60-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CF40-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CF50-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CG20-0AA0	SIMATIC DP, 1 TERMINALMODUL
6ES7193-4CG30-0AA0	SIMATIC DP, 1 TERMINALMODUL
6ES7193-4CK20-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CK30-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-4CL20-0AA0	SIMATIC DP, 1 TERMINALMODUL
6ES7193-4CL30-0AA0	SIMATIC DP, 1 TERMINALMODUL
6ES7193-4GA00-0AA0	5 SCHIRMAUFLAGEELEMENTE FUER
6ES7193-4GB00-0AA0	5 SCHIRMKLEMMEN FUER ET 200S
6ES7193-4JA00-0AA0	SIMATIC DP, ERSATZTEIL
6ES7193-4KA00-0AA0	SIMATIC DP, ERSATZSICHERUNGEN
6ES7193-4KA10-0AA0	SIMATIC DP, ERSATZSICHERUNGEN
6ES7193-5CB00-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-5CB10-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-5DA00-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-5DB00-0AA0	SIMATIC DP, TERMINALMODUL
6ES7193-8LA00-0AA0	SIMATIC DP, LADEGERAET 230V
6ES7193-8LB00-0AA0	SIMATIC DP, LADEGERAET 110V
6ES7194-1AA00-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7194-1AA01-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7194-1AB00-0XA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1AB01-0XA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1EA00-0XA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1FC00-0XA0	SIMATIC DP, STECKERPLATTE
6ES7194-1JA00-0XA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1JB00-0XA0	SIMATIC DP, DEZENTR. PERIPHERIE

Order No.	Description
6ES7194-1JB10-0XA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1KA01-0XA0	SIMATIC DP, Y-ANSCHLUSSSTUECK
6ES7194-1KB00-0XA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1LA00-0AA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1LA01-0AA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1LB00-0AA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1LB01-0AA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1LC00-0AA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1LC01-0AA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1LD00-0AA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-1LD01-0AA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7194-3AA00-0AA0	SIMATIC DP, ANSCHLUSSBLOCK
6ES7194-3AA00-0BA0	SIMATIC DP, ANSCHLUSSBLOCK
6ES7194-3JA00-0AA0	SIMATIC DP, VERSCHLUSSKAPPEN
6ES7194-5AA00-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7195-1BE00-0XA0	SIMATIC DP, STECKADAPTER
6ES7195-1JA00-0XA0	SIMATIC DP, ABDECKUNG F. BUSMODUL
6ES7195-1KA00-0XA0	SIMATIC DP, EX - TRENNWAND
6ES7195-7HA00-0XA0	SIMATIC DP, BUSMODUL F. ET 200M
6ES7195-7HB00-0XA0	SIMATIC DP, BUSMODUL F. ET 200M
6ES7195-7HC00-0XA0	SIMATIC DP, BUSMODUL F. ET 200M
6ES7195-7HD00-0XA0	SIMATIC DP, BUSMODUL F. ET 200M
6ES7195-7HD10-0XA0	SIMATIC DP, BUSMODUL F. ET 200M
6ES7195-7HG00-0XA0	SIMATIC S7, TRENNBUSMODUL
6ES7195-7KF00-0XA0	SIMATIC S7, TRENNBAUGRUPPE
6ES7197-1LB00-0XA0	SIMATIC S7, Y-KOPPLER
6ES7210-0AA00-0XB0	SIMATIC S7-200, CPU 210
6ES7210-0BA00-0XB0	SIMATIC S7-200, CPU 210
6ES7210-0CA00-0XB0	SIMATIC S7-200, CPU 210
6ES7210-8XX00-6AA0	SIMATIC S7-200,
6ES7211-0AA20-0XB0	SIMATIC S7-200, CPU 221
6ES7211-0AA21-0XB0	SIMATIC S7-200, CPU 221
6ES7211-0AA22-0XB0	SIMATIC S7-200, CPU 221
6ES7211-0BA20-0XB0	SIMATIC S7-200, CPU 221
6ES7211-0BA21-0XB0	SIMATIC S7-200, CPU 221
6ES7211-0BA22-0XB0	SIMATIC S7-200, CPU 221
6ES7212-1AA00-0XB0	SIMATIC S7-200, CPU 212
6ES7212-1AA01-0XB0	SIMATIC S7-200, CPU 212
6ES7212-1AB20-0XB0	SIMATIC S7-200, CPU 222
6ES7212-1AB21-0XB0	SIMATIC S7-200, CPU 222
6ES7212-1AB22-0XB0	SIMATIC S7-200, CPU 222
6ES7212-1BA00-0XB0	SIMATIC S7-200, CPU 212
6ES7212-1BA01-0XB0	SIMATIC S7-200, CPU 212
6ES7212-1BA10-0XB0	SIMATIC S7-200, CPU 212
6ES7212-1BB20-0XB0	SIMATIC S7-200, CPU 222
6ES7212-1BB21-0XB0	SIMATIC S7-200, CPU 222
6ES7212-1BB22-0XB0	SIMATIC S7-200, CPU 222
6ES7212-1CA00-0XB0	SIMATIC S7-200, CPU 212
6ES7212-1CA01-0XB0	SIMATIC S7-200, CPU 212
6ES7212-1DA01-0XB0	SIMATIC S7-200, CPU 212
6ES7212-1FA01-0XB0	SIMATIC S7-200, CPU 212

Order No.	Description
6ES7212-1GA01-0XB0	SIMATIC S7-200, CPU 212
6ES7214-1AC00-0XB0	SIMATIC S7-200, CPU 214
6ES7214-1AC01-0XB0	SIMATIC S7-200, CPU 214
6ES7214-1AD20-0XB0	SIMATIC S7-200, CPU 224
6ES7214-1AD21-0XB0	SIMATIC S7-200, CPU 224
6ES7214-1AD22-0XB0	SIMATIC S7-200, CPU 224
6ES7214-1AD23-0XB0	SIMATIC S7-200, CPU 224
6ES7214-1BC00-0XB0	SIMATIC S7-200, CPU 214
6ES7214-1BC01-0XB0	SIMATIC S7-200, CPU 214
6ES7214-1BC10-0XB0	SIMATIC S7-200, CPU 214
6ES7214-1BD20-0XB0	SIMATIC S7-200, CPU 224
6ES7214-1BD21-0XB0	SIMATIC S7-200, CPU 224
6ES7214-1BD22-0XB0	SIMATIC S7-200, CPU 224
6ES7214-1BD23-0XB0	SIMATIC S7-200, CPU 224
6ES7214-1CC00-0XB0	SIMATIC S7-200, CPU 214
6ES7214-1CC01-0XB0	SIMATIC S7-200, CPU 214
6ES7214-1DC01-0XB0	SIMATIC S7-200, CPU 214
6ES7214-1GC01-0XB0	SIMATIC S7-200, CPU 214
6ES7214-2AD23-0XB0	SIMATIC S7-200, CPU 224XP
6ES7214-2BD23-0XB0	SIMATIC S7-200, CPU 224XP
6ES7215-2AD00-0XB0	SIMATIC S7-200, CPU 215
6ES7215-2BD00-0XB0	SIMATIC S7-200, CPU 215
6ES7216-2AD00-0XB0	SIMATIC S7-200, CPU 216
6ES7216-2AD21-0XB0	SIMATIC S7-200, CPU 226
6ES7216-2AD22-0XB0	SIMATIC S7-200, CPU 226
6ES7216-2AD23-0XB0	SIMATIC S7-200, CPU 226
6ES7216-2AF21-0XB0	SIMATIC S7-200, CPU 226 XM
6ES7216-2AF22-0XB0	SIMATIC S7-200, CPU 226 XM
6ES7216-2BD00-0XB0	SIMATIC S7-200, CPU 216
6ES7216-2BD21-0XB0	SIMATIC S7-200, CPU 226
6ES7216-2BD22-0XB0	SIMATIC S7-200, CPU 226
6ES7216-2BD23-0XB0	SIMATIC S7-200, CPU 226
6ES7216-2BF21-0XB0	SIMATIC S7-200, CPU 226 XM
6ES7216-2BF22-0XB0	SIMATIC S7-200, CPU 226 XM
6ES7221-1BF00-0XA0	SIMATIC S7-200, DIGITALEINGABE
6ES7221-1BF10-0XA0	SIMATIC S7-200, DIGITALEINGABE
6ES7221-1BF21-0XA0	SIMATIC S7-200, DIGITALEINGABE
6ES7221-1BF22-0XA0	SIMATIC S7-200, DIGITALEINGABE
6ES7221-1BH22-0XA0	SIMATIC S7-200, DIGITALEINGABE
6ES7221-1EF00-0XA0	SIMATIC S7-200, DIGITALEINGABE
6ES7221-1EF22-0XA0	SIMATIC S7-200, DIGITALEINGABE
6ES7221-1JF00-0XA0	SIMATIC S7-200, DIGITALEINGABE
6ES7222-1BD22-0XA0	SIMATIC S7-200, DIGITALAUSGABE
6ES7222-1BF00-0XA0	SIMATIC S7-200, DIGITALAUSGABE
6ES7222-1BF21-0XA0	SIMATIC S7-200, DIGITALAUSGABE
6ES7222-1BF22-0XA0	SIMATIC S7-200, DIGITALAUSGABE
6ES7222-1EF00-0XA0	SIMATIC S7-200, DIGITALAUSGABE
6ES7222-1EF22-0XA0	SIMATIC S7-200, DIGITALAUSGABE
6ES7222-1HD22-0XA0	SIMATIC S7-200, DIGITALAUSGABE
6ES7222-1HF00-0XA0	SIMATIC S7-200, DIGITALAUSGABE
6ES7222-1HF21-0XA0	SIMATIC S7-200, DIGITALAUSGABE

Order No.	Description
6ES7222-1HF22-0XA0	SIMATIC S7-200, DIGITALAUSGABE
6ES7223-1BF00-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1BF21-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1BF22-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1BH00-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1BH21-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1BH22-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1BL00-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1BL21-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1BL22-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1EF00-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1HF00-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1HF21-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1HF22-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1PH00-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1PH21-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1PH22-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1PL00-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1PL21-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7223-1PL22-0XA0	SIMATIC S7-200, DIGITALE E/A
6ES7231-0HC00-0XA0	SIMATIC S7-200, ANALOGEINGABE
6ES7231-0HC21-0XA0	SIMATIC S7-200, ANALOGEINGABE
6ES7231-0HC22-0XA0	SIMATIC S7-200, ANALOGEINGABE
6ES7231-7PB21-0XA0	SIMATIC S7-200, ANALOGEINGABE
6ES7231-7PB22-0XA0	SIMATIC S7-200, ANALOGEINGABE
6ES7231-7PD20-0XA0	SIMATIC S7-200, ANALOGEINGABE
6ES7231-7PD21-0XA0	SIMATIC S7-200, ANALOGEINGABE
6ES7231-7PD22-0XA0	SIMATIC S7-200, ANALOGEINGABE
6ES7232-0HB00-0XA0	SIMATIC S7-200, ANALOGAUSGABE
6ES7232-0HB21-0XA0	SIMATIC S7-200, ANALOGAUSGABE
6ES7232-0HB22-0XA0	SIMATIC S7-200, ANALOGAUSGABE
6ES7235-0KD00-0XA0	SIMATIC S7-200, ANALOGE E/A
6ES7235-0KD21-0XA0	SIMATIC S7-200, ANALOGE E/A
6ES7235-0KD22-0XA0	SIMATIC S7-200, ANALOGE E/A
6ES7241-1AA22-0XA0	SIMATIC S7-200, MODEM ERW.MODUL
6ES7253-1AA22-0XA0	SIMATIC S7-200, EM253
6ES7272-0AA00-4AA0	SIMATIC S7, TD 200 TEXT DISPLAY
6ES7272-0AA20-0YA0	SIMATIC S7, TD 200 TEXTDISPLAY
6ES7272-0AA30-0YA0	SIMATIC S7, TD 200 TEXTDISPLAY
6ES7272-1AA10-0YA0	SIMATIC S7-200, TD200C
6ES7274-1XF00-0XA0	SIMATIC S7-200,SIMULATOR MODUL
6ES7274-1XH00-0XA0	SIMATIC S7-200,SIMULATOR MODUL
6ES7274-1XK00-0XA0	SIMATIC S7-200,SIMULATOR MODUL
6ES7277-0AA20-0XA0	SIMATIC S7-200, PROFIBUS DP
6ES7277-0AA21-0XA0	SIMATIC S7-200, PROFIBUS DP
6ES7277-0AA22-0XA0	SIMATIC S7-200, PROFIBUS DP
6ES7290-0AA00-0XA0	SIMATIC S7-200, BUSVERBINDER
6ES7290-2AA00-0XA0	SIMATIC S7-200, KLEMMENBLOCK
6ES7290-2BA00-0XA0	SIMATIC S7-200, KLEMMENBLOCK
6ES7290-2CA00-0XA0	SIMATIC S7-200, KLEMMENBLOCK
6ES7290-6AA20-0XA0	SIMATIC S7-200, VERLAENGERUNGS-

Order No.	Description
6ES7290-6BC50-0XA0	SIMATIC S7-200, VERLAENGERUNGS-
6ES7291-3AX00-0XA0	SIMATIC S7-200, FRONTKLAPPEN
6ES7291-3AX20-0XA0	SIMATIC S7-200, FRONTKLAPPENSET
6ES7291-3BX00-0XA0	SIMATIC S7-200, FRONTKLAPPEN
6ES7291-8BA00-0XA0	SIMATIC S7-200, BATTERIEMODUL
6ES7291-8BA20-0XA0	SIMATIC S7-200, BATTERIEMODUL
6ES7291-8GC00-0XA0	SIMATIC S7, SPEICHERMODUL
6ES7291-8GD00-0XA0	SIMATIC S7, SPEICHERMODUL
6ES7291-8GE20-0XA0	SIMATIC S7-200, SPEICHERMODUL
6ES7291-8GF23-0XA0	SIMATIC S7-200, SPEICHERMODUL
6ES7291-8GH23-0XA0	SIMATIC S7-200, SPEICHERMODUL
6ES7292-1AD20-0AA0	SIMATIC S7-200, ERSATZTEIL
6ES7292-1AE20-0AA0	SIMATIC S7-200, ERSATZTEIL
6ES7292-1AF20-0AA0	SIMATIC S7-200, ERSATZTEIL
6ES7292-1AG20-0AA0	SIMATIC S7-200, ERSATZTEIL
6ES7292-3AX00-0XA0	SIMATIC S7-200, FRONTKLAPPEN
6ES7297-1AA20-0XA0	SIMATIC S7-200,
6ES7307-1AE04-0AB0	SIMATIC S7, Netzteil
6ES7312-1AD10-0AB0	SIMATIC S7-300, CPU 312
6ES7312-5AC00-0AB0	SIMATIC S7-300, CPU 312 IFM
6ES7312-5AC01-0AB0	SIMATIC S7-300, CPU 312 IFM
6ES7312-5AC02-0AB0	SIMATIC S7-300, CPU 312 IFM
6ES7312-5AC81-0AB0	SIMATIC S7-300, CPU 312 IFM
6ES7312-5AC82-0AB0	SIMATIC S7-300, CPU 312 IFM
6ES7312-5BD00-0AB0	SIMATIC S7-300, CPU 312C
6ES7312-5BD01-0AB0	SIMATIC S7-300, CPU 312C
6ES7313-1AD00-0AB0	SIMATIC S7-300, CPU 313
6ES7313-1AD01-0AB0	SIMATIC S7-300, CPU 313
6ES7313-1AD02-0AB0	SIMATIC S7-300, CPU 313
6ES7313-1AD03-0AB0	SIMATIC S7-300, CPU 313
6ES7313-5BE00-0AB0	SIMATIC S7-300, CPU 313C
6ES7313-5BE01-0AB0	SIMATIC S7-300, CPU 313C
6ES7313-6BE00-0AB0	SIMATIC S7-300, CPU 313C-2 PTP
6ES7313-6BE01-0AB0	SIMATIC S7-300, CPU 313C-2 PTP
6ES7313-6CE00-0AB0	SIMATIC S7-300, CPU 313C-2 DP
6ES7313-6CE01-0AB0	SIMATIC S7-300, CPU 313C-2 DP
6ES7314-1AE01-0AB0	SIMATIC S7-300, CPU 314
6ES7314-1AE02-0AB0	SIMATIC S7-300, CPU 314
6ES7314-1AE03-0AB0	SIMATIC S7-300, CPU 314
6ES7314-1AE04-0AB0	SIMATIC S7-300, CPU 314
6ES7314-1AE83-0AB0	SIMATIC S7-300, CPU 314
6ES7314-1AE84-0AB0	SIMATIC S7-300, CPU 314
6ES7314-1AF10-0AB0	SIMATIC S7-300, CPU 314
6ES7314-5AE00-0AB0	SIMATIC S7-300, CPU 314 IFM
6ES7314-5AE01-0AB0	SIMATIC S7-300, CPU 314 IFM
6ES7314-5AE02-0AB0	SIMATIC S7-300, CPU 314 IFM
6ES7314-5AE03-0AB0	SIMATIC S7-300, CPU 314 IFM
6ES7314-5AE10-0AB0	SIMATIC S7-300, CPU 314 IFM
6ES7314-5AE83-0AB0	SIMATIC S7-300, CPU 314 IFM
6ES7314-6BF00-0AB0	SIMATIC S7-300, CPU 314C-2 PTP
6ES7314-6BF01-0AB0	SIMATIC S7-300, CPU 314C-2 PTP

Order No.	Description
6ES7314-6CF00-0AB0	SIMATIC S7-300, CPU 314C-2 DP
6ES7314-6CF01-0AB0	SIMATIC S7-300, CPU 314C-2 DP
6ES7315-1AF00-0AB0	SIMATIC S7-300, CPU 315
6ES7315-1AF01-0AB0	SIMATIC S7-300, CPU 315
6ES7315-1AF02-0AB0	SIMATIC S7-300, CPU 315
6ES7315-1AF03-0AB0	SIMATIC S7-300, CPU 315
6ES7315-2AF00-0AB0	SIMATIC S7-300, CPU 315-2 DP
6ES7315-2AF01-0AB0	SIMATIC S7-300, CPU 315-2 DP
6ES7315-2AF02-0AB0	SIMATIC S7-300, CPU 315-2 DP
6ES7315-2AF03-0AB0	SIMATIC S7-300, CPU 315-2 DP
6ES7315-2AF82-0AB0	SIMATIC S7-300, CPU 315-2 DP
6ES7315-2AF83-0AB0	SIMATIC S7-300, CPU 315-2 DP
6ES7315-2AG10-0AB0	SIMATIC S7-300, CPU 315-2DP
6ES7315-6FF00-0AB0	SIMATIC S7-300, CPU 315F
6ES7315-6FF01-0AB0	SIMATIC S7-300, CPU 315F
6ES7316-1AG00-0AB0	SIMATIC S7-300, CPU 316
6ES7316-2AG00-0AB0	SIMATIC S7-300, CPU 316-2DP
6ES7317-2AJ10-0AB0	SIMATIC S7-300, CPU 317-2DP,
6ES7317-2EJ10-0AB0	SIMATIC S7-300 CPU 317-2 PN/DP,
6ES7317-6FF00-0AB0	SIMATIC S7-300, CPU 317F-2DP,
6ES7317-6TJ10-0AB0	SIMATIC S7-300, CPU 317T-2 DP,
6ES7318-2AJ00-0AB0	SIMATIC S7-300, CPU 318-2 DP
6ES7321-1BH00-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1BH01-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1BH02-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1BH10-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1BH50-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1BH81-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1BH82-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1BL00-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1BL80-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1CH00-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1CH20-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1CH80-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1EH00-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1EH01-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1EL00-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1FF00-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1FF01-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1FF10-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1FF81-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-1FH00-0AA0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-7BH00-0AB0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-7BH01-0AB0	SIMATIC S7-300, DIGITALEINGABE
6ES7321-7BH80-0AB0	SIMATIC S7-300, DIGITALEINGABE
6ES7322-1BF00-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1BF01-0AA0	SIMATIC S7-300, DIGITALAUSGABE 8x 24V DC / 2A
6ES7322-1BH00-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1BH01-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1BH10-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1BH81-0AA0	SIMATIC S7-300, DIGITALAUSGABE

Order No.	Description
6ES7322-1BL00-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1CF00-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1CF80-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1EH00-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1EH01-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1EL00-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1FF00-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1FF01-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1FF81-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1FH00-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1FL00-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1HF00-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1HF01-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1HF10-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1HF20-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1HF80-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1HH00-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-1HH01-0AA0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-5FF00-0AB0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-5GH00-0AB0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-5HF00-0AB0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-8BF00-0AB0	SIMATIC S7-300, DIGITALAUSGABE
6ES7322-8BF80-0AB0	SIMATIC S7-300, DIGITALAUSGABE
6ES7323-1BH00-0AA0	SIMATIC S7-300,DIGITALBAUGRUPPE
6ES7323-1BH01-0AA0	SIMATIC S7-300,DIGITALBAUGRUPPE
6ES7323-1BH80-0AA0	SIMATIC S7-300,DIGITALBAUGRUPPE
6ES7323-1BH81-0AA0	SIMATIC S7-300,DIGITALBAUGRUPPE
6ES7323-1BL00-0AA0	SIMATIC S7-300,DIGITALBAUGRUPPE
6ES7326-1BK00-0AB0	SIMATIC S7, DIGITALEINGABE
6ES7326-1RF00-0AB0	SIMATIC S7, DIGITALEINGABE
6ES7326-2BF00-0AB0	SIMATIC S7, DIGITALAUSGABE
6ES7326-2BF01-0AB0	SIMATIC S7, DIGITALAUSGABE
6ES7327-1BH00-0AB0	SIMATIC S7-300,DIGITALBAUGRUPPE
6ES7328-0AA00-7AA0	SIMATIC S7-300, FRONTTUER
6ES7331-1KF00-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-1KF01-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7HF00-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7HF01-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7KB00-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7KB01-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7KB02-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7KB81-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7KB82-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7KF00-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7KF01-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7KF02-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7NF00-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7NF10-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7PF00-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7331-7PF10-0AB0	SIMATIC S7-300, ANALOGEINGABE
6ES7332-5HB00-0AB0	SIMATIC S7-300, ANALOGAUSGABE

Order No.	Description
6ES7332-5HB01-0AB0	SIMATIC S7-300, ANALOGAUSGABE
6ES7332-5HB81-0AB0	SIMATIC S7-300, ANALOGAUSGABE
6ES7332-5HD00-0AB0	SIMATIC S7-300, ANALOGAUSGABE
6ES7332-5HD01-0AB0	SIMATIC S7-300, ANALOGAUSGABE
6ES7332-5HF00-0AB0	SIMATIC S7-300, ANALOGAUSGABE
6ES7332-7ND00-0AB0	SIMATIC S7-300, ANALOGAUSGABE
6ES7332-7ND01-0AB0	SIMATIC S7-300, ANALOGAUSGABE
6ES7334-0CE00-0AA0	SIMATIC S7-300, ANALOGBAUGRUPPE
6ES7334-0CE01-0AA0	SIMATIC S7-300, ANALOGBAUGRUPPE
6ES7334-0KE00-0AB0	SIMATIC S7-300, ANALOGBAUGRUPPE
6ES7334-0KE80-0AB0	SIMATIC S7-300, ANALOGBAUGRUPPE
6ES7336-1HE00-0AB0	SIMATIC S7, ANALOGEINGABE
6ES7338-4BC00-0AB0	SIMATIC S7-300, SIGNALBAUGRUPPE
6ES7338-4BC01-0AB0	SIMATIC S7-300, SIGNALBAUGRUPPE
6ES7338-7XF00-0AB0	SIMATIC S7-300, IQ-SENSE
6ES7340-1AH01-0AE0	SIMATIC S7-300, CP 340
6ES7340-1BH00-0AE0	SIMATIC S7-300, CP 340
6ES7340-1CH00-0AE0	SIMATIC S7-300, CP 340
6ES7341-1AH01-0AE0	SIMATIC S7-300, CP341
6ES7341-1BH01-0AE0	SIMATIC S7-300, CP341
6ES7341-1CH01-0AE0	SIMATIC S7-300, CP341
6ES7350-1AH00-0AE0	SIMATIC S7-300,ZAEHLERBAUGRUPPE
6ES7350-1AH01-0AE0	SIMATIC S7/M7, ZAEHLERBAUGRUPPE
6ES7350-1AH02-0AE0	SIMATIC S7-300,ZAEHLERBAUGRUPPE
6ES7350-1AH03-0AE0	SIMATIC S7-300,ZAEHLERBAUGRUPPE
6ES7350-2AH00-0AE0	SIMATIC S7-300,ZAEHLERBAUGRUPPE
6ES7351-1AH01-0AE0	SIMATIC S7-300,POSITIONIERBAUGR
6ES7352-1AH01-0AE0	SIMATIC S7-300, NOCKENSTEUERW.,
6ES7352-5AH00-0AE0	SIMATIC S7-300, FM352-5
6ES7352-5AH10-0AE0	SIMATIC S7-300, FM352-5
6ES7355-0VH10-0AE0	SIMATIC S7-300, REGELUNGSBAUGR.
6ES7355-1VH00-0AE0	SIMATIC S7-300, REGELUNGSBAU-
6ES7355-1VH10-0AE0	SIMATIC S7-300, REGELUNGSBAUGR.
6ES7355-2CH00-0AE0	SIMATIC S7-300, TEMPERATUR
6ES7355-2SH00-0AE0	SIMATIC S7-300, TEMPERATUR-
6ES7356-4BM00-0AE0	SIMATIC M7-300,
6ES7356-4BN00-0AE0	SIMATIC M7-300,
6ES7360-3AA01-0AA0	SIMATIC S7-300, ANSCHALTUNG
6ES7361-3CA01-0AA0	SIMATIC S7-300, ANSCHALTUNG
6ES7365-0BA01-0AA0	SIMATIC S7-300, ANSCHALTUNG
6ES7365-0BA81-0AA0	SIMATIC S7-300, ANSCHALTUNG
6ES7370-0AA01-0AA0	SIMATIC S7-300, DUMMYBAUGRUPPE
6ES7374-2XH01-0AA0	SIMATIC S7-300, SIMULATORBGR.
6ES7378-2AB00-0AC0	SIMATIC M7-300,
6ES7378-2AC00-0AC0	SIMATIC M7-300,
6ES7378-2BA00-0AC0	SIMATIC M7-300,
6ES7388-4BN00-0AC0	SIMATIC M7-300, CPU388-4
6ES7390-0AA00-0AA0	SIMATIC S7, BUSVERBINDER
6ES7391-1AA00-0AA0	SIMATIC S7-300, ERSATZTEIL
6ES7392-1AJ00-0AA0	SIMATIC S7-300, FRONTSTECKER
6ES7392-1AM00-0AA0	SIMATIC S7-300, FRONTSTECKER

Order No.	Description
6ES7392-1BJ00-0AA0	SIMATIC S7-300, FRONTSTECKER
6ES7392-1BM01-0AA0	SIMATIC S7-300, FRONTSTECKER
6ES7393-4AA10-0AA0	SIMATIC S7-300, LEITUNGSKAMMER
6ES7400-1JA00-0AA0	SIMATIC S7-400, BAUGR.TRAEGER
6ES7400-1JA01-0AA0	SIMATIC S7-400, BAUGR.TRAEGER
6ES7400-1TA00-0AA0	SIMATIC S7-400, BAUGR.TRAEGER
6ES7400-1TA01-0AA0	SIMATIC S7-400, BAUGR.TRAEGER
6ES7400-2JA00-0AA0	SIMATIC S7-400H, BAUGR.TRAEGER
6ES7401-1DA01-0AA0	SIMATIC S7-400, BAUGR.TRAEGER
6ES7401-2TA00-0AA0	SIMATIC S7-400, BAUGR.TRAEGER
6ES7401-2TA01-0AA0	SIMATIC S7-400, BAUGR.TRAEGER
6ES7403-1JA00-0AA0	SIMATIC S7-400,
6ES7403-1JA01-0AA0	SIMATIC S7-400,
6ES7403-1TA00-0AA0	SIMATIC S7-400,
6ES7403-1TA01-0AA0	SIMATIC S7-400,
6ES7405-0DA00-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7405-0DA01-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7405-0KA00-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7405-0KA01-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7405-0KR00-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7405-0RA00-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7405-0RA01-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7407-0DA00-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7407-0DA01-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7407-0KA00-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7407-0KA01-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7407-0KR00-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7407-0RA00-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7407-0RA01-0AA0	SIMATIC S7-400, STROMVERSORGUNG
6ES7408-0TA00-0AA0	SIMATIC S7-400, KABELKANAL
6ES7408-1TA00-0XA0	SIMATIC S7-400, LUEFTERZEILE
6ES7408-1TA00-6AA0	SIMATIC S7-400,AUSTAUSCHLUEFTER
6ES7408-1TA00-7AA0	SIMATIC S7-400, STAUBFILTER
6ES7408-1TA01-0XA0	SIMATIC S7-400, LUEFTERZEILE
6ES7408-1TB00-0XA0	SIMATIC S7-400, LUEFTERZEILE
6ES7408-1TX00-6XA0	SIMATIC S7-400, ERSATZTEIL
6ES7408-1XX00-6XA0	SIMATIC S7-400, ERSATZTEIL
6ES7412-1XF00-0AB0	SIMATIC S7-400, CPU 412-1
6ES7412-1XF01-0AB0	SIMATIC S7-400, CPU 412-1
6ES7412-1XF02-0AB0	SIMATIC S7-400, CPU 412-1
6ES7412-1XF03-0AB0	SIMATIC S7-400, CPU 412-1
6ES7412-1XF04-0AB0	SIMATIC S7-400, CPU 412-1
6ES7412-2XG00-0AB0	SIMATIC S7-400, CPU 412-2
6ES7412-2XG04-0AB0	SIMATIC S7-400, CPU 412-2
6ES7413-1XG00-0AB0	SIMATIC S7-400, CPU 413-1
6ES7413-1XG01-0AB0	SIMATIC S7-400, CPU 413-1
6ES7413-1XG02-0AB0	SIMATIC S7-400, CPU 413-1
6ES7413-2XG00-0AB0	SIMATIC S7-400, CPU 413-2 DP
6ES7413-2XG01-0AB0	SIMATIC S7-400, CPU 413-2 DP
6ES7413-2XG02-0AB0	SIMATIC S7-400, CPU 413-2 DP
6ES7414-1XG00-0AB0	SIMATIC S7-400, CPU 414-1

Order No.	Description
6ES7414-1XG01-0AB0	SIMATIC S7-400, CPU 414-1
6ES7414-1XG02-0AB0	SIMATIC S7-400, CPU 414-1
6ES7414-2XG00-0AB0	SIMATIC S7-400, CPU 414-2 DP
6ES7414-2XG01-0AB0	SIMATIC S7-400, CPU 414-2 DP
6ES7414-2XG02-0AB0	SIMATIC S7-400, CPU 414-2 DP
6ES7414-2XG03-0AB0	SIMATIC S7-400, CPU 414-2
6ES7414-2XG04-0AB0	SIMATIC S7-400, CPU 414-2
6ES7414-2XJ00-0AB0	SIMATIC S7-400, CPU 414-2 DP
6ES7414-2XJ01-0AB0	SIMATIC S7-400, CPU 414-2 DP
6ES7414-3XJ00-0AB0	SIMATIC S7-400, CPU 414-3
6ES7414-3XJ04-0AB0	SIMATIC S7-400, CPU 414-3
6ES7414-4HJ00-0AB0	SIMATIC S7-400H, CPU 414H
6ES7414-4HJ04-0AB0	SIMATIC S7-400H, CPU 414H
6ES7416-1XJ00-0AB0	SIMATIC S7-400, CPU 416-1
6ES7416-1XJ01-0AB0	SIMATIC S7-400, CPU 416-1
6ES7416-1XJ02-0AB0	SIMATIC S7-400, CPU 416-1
6ES7416-2FK02-0AB0	SIMATIC S7-400, CPU 416F-2
6ES7416-2FK04-0AB0	SIMATIC S7-400, CPU 416F-2
6ES7416-2XK00-0AB0	SIMATIC S7-400, CPU 416-2 DP
6ES7416-2XK01-0AB0	SIMATIC S7-400, CPU 416-2 DP
6ES7416-2XK01-0AB1	SIMATIC S7-400, ERSATZTEIL KIT
6ES7416-2XK02-0AB0	SIMATIC S7-400, CPU 416-2
6ES7416-2XK04-0AB0	SIMATIC S7-400, CPU 416-2
6ES7416-2XL00-0AB0	SIMATIC S7-400, CPU 416-2 DP
6ES7416-2XL01-0AB0	SIMATIC S7-400, CPU 416-2 DP
6ES7416-2XL01-0AB1	SIMATIC S7-400, ERSATZTEIL KIT
6ES7416-3XL00-0AB0	SIMATIC S7-400, CPU 416-3
6ES7416-3XL04-0AB0	SIMATIC S7-400, CPU 416-3
6ES7417-4HL00-0AB0	SIMATIC S7-400H, CPU 417H
6ES7417-4HL01-0AB0	SIMATIC S7-400H, CPU 417H
6ES7417-4HL04-0AB0	SIMATIC S7-400H, CPU 417H
6ES7417-4XL00-0AB0	SIMATIC S7-400, CPU 417-4
6ES7417-4XL04-0AB0	SIMATIC S7-400, CPU 417-4
6ES7421-1BL00-0AA0	SIMATIC S7-400, DIGITALEINGABE
6ES7421-1BL01-0AA0	SIMATIC S7-400, DIGITALEINGABE
6ES7421-1EL00-0AA0	SIMATIC S7-400, DIGITALEINGABE
6ES7421-1FH00-0AA0	SIMATIC S7-400, DIGITALEINGABE
6ES7421-1FH20-0AA0	SIMATIC S7-400, DIGITALEINGABE
6ES7421-5EH00-0AA0	SIMATIC S7-400, DIGITALEINGABE
6ES7421-7BH00-0AB0	SIMATIC S7-400, DIGITALEINGABE
6ES7421-7BH01-0AB0	SIMATIC S7-400, DIGITALEINGABE
6ES7421-7DH00-0AB0	SIMATIC S7-400, DIGITALEINGABE
6ES7422-0XX00-7AA0	SIMATIC S7-400, ERSATZTEIL
6ES7422-1BH10-0AA0	SIMATIC S7-400, DIGITALAUSGABE
6ES7422-1BH11-0AA0	SIMATIC S7-400, DIGITALAUSGABE
6ES7422-1BL00-0AA0	SIMATIC S7-400, DIGITALAUSGABE
6ES7422-1FF00-0AA0	SIMATIC S7-400, DIGITALAUSGABE
6ES7422-1FH00-0AA0	SIMATIC S7-400, DIGITALAUSGABE
6ES7422-1HH00-0AA0	SIMATIC S7-400, DIGITALAUSGABE
6ES7422-5EH00-0AB0	SIMATIC S7-400, DIGITALAUSGABE
6ES7422-5EH10-0AB0	SIMATIC S7-400, DIGITALAUSGABE

Order No.	Description
6ES7422-7BL00-0AB0	SIMATIC S7-400, DIGITALAUSGABE
6ES7431-0HH00-0AB0	SIMATIC S7-400, ANALOGEINGABE
6ES7431-1KF00-0AB0	SIMATIC S7-400, ANALOGEINGABE
6ES7431-1KF10-0AB0	SIMATIC S7-400, ANALOGEINGABE
6ES7431-1KF20-0AB0	SIMATIC S7-400, ANALOGEINGABE
6ES7431-7KF00-0AB0	SIMATIC S7-400, ANALOGEINGABE
6ES7431-7KF00-6AA0	SIMATIC S7-400, FRONTSTECKER
6ES7431-7KF10-0AB0	SIMATIC S7-400, ANALOGEINGABE
6ES7431-7QH00-0AB0	SIMATIC S7-400, ANALOGEINGABE
6ES7432-1HF00-0AB0	SIMATIC S7-400, ANALOGAUSGABE
6ES7440-1CS00-0YE0	SIMATIC S7-400, KOPPLUNGSBAUGR.
6ES7441-1AA02-0AE0	SIMATIC S7-400, KOPPLUNGSBAUGR.
6ES7441-1AA03-0AE0	SIMATIC S7-400, KOPPLUNGSBAUGR.
6ES7441-2AA02-0AE0	SIMATIC S7-400, KOPPLUNGSBAUGR.
6ES7441-2AA03-0AE0	SIMATIC S7-400, KOPPLUNGSBAUGR.
6ES7443-1EX11-0XE0	SIMATIC S7-400, CP443-1
6ES7444-1MX00-0XE0	SIMATIC S7-400, KOMMUNIK.BAUGR.
6ES7450-1AP00-0AE0	SIMATIC S7-400, FUNKTIONSMODUL
6ES7451-3AL00-0AE0	SIMATIC S7-400, POSITIONIERBAUGR
6ES7452-1AH00-0AE0	SIMATIC S7-400, NOCKENSTEUERWERK
6ES7453-3AH00-0AE0	SIMATIC S7-400, FUNKTIONSBaugr.
6ES7455-0VS00-0AE0	SIMATIC S7-400, REGELUNGSBAU-
6ES7455-1VS00-0AE0	SIMATIC S7-400, REGELUNGSBAU-
6ES7456-2AA00-0AB0	SIMATIC M7-400, FM456-2
6ES7456-4EY00-0AE0	SIMATIC M7-400,
6ES7460-0AA00-0AB0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7460-0AA01-0AB0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7460-1BA00-0AB0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7460-1BA01-0AB0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7460-3AA00-0AB0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7460-3AA01-0AB0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7460-4AA01-0AB0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7461-0AA00-0AA0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7461-0AA00-7AA0	SIMATIC S7-400, ABSCHLUSSSTECKER
6ES7461-0AA01-0AA0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7461-1BA00-0AA0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7461-1BA00-7AA0	SIMATIC S7-400, ABSCHLUSSSTECKER
6ES7461-1BA01-0AA0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7461-3AA00-0AA0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7461-3AA00-7AA0	SIMATIC S7-400, ABSCHLUSSSTECKER
6ES7461-3AA01-0AA0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7461-4AA00-7AA0	SIMATIC S7-400, ABSCHLUSSSTECKER
6ES7461-4AA01-0AA0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7463-2AA00-0AA0	SIMATIC S7-400, ANSCHALTBAUGR.
6ES7467-5FJ00-0AB0	SIMATIC S7-400, ANSCHALT. IM467
6ES7467-5GJ00-0AB0	SIMATIC S7-400, ANSCHALT. IM467
6ES7467-5GJ01-0AB0	SIMATIC S7-400, ANSCHALT. IM467
6ES7467-5GJ02-0AB0	SIMATIC S7-400, ANSCHALT. IM467
6es7468-1AH50-0AA0	SIMATIC S7-400, IM-KABEL
6ES7468-1BB50-0AA0	SIMATIC S7-400, IM-KABEL
6ES7468-1BF00-0AA0	SIMATIC S7-400, IM-KABEL

Order No.	Description
6ES7468-1CB00-0AA0	SIMATIC S7-400, IM-KABEL
6ES7468-1CC50-0AA0	SIMATIC S7-400, IM-KABEL
6ES7468-1CF00-0AA0	SIMATIC S7-400, IM-KABEL
6ES7468-1DB00-0AA0	SIMATIC S7-400, IM-KABEL
6ES7468-1DC50-0AA0	SIMATIC S7-400, IM-KABEL,
6ES7468-1DE50-0AA0	SIMATIC S7-400, IM-KABEL,
6ES7468-1DG00-0AA0	SIMATIC S7-400, IM-KABEL,
6ES7468-3AH50-0AA0	SIMATIC S7-400, IM-KABEL
6ES7468-3BB50-0AA0	SIMATIC S7-400, IM-KABEL
6ES7470-0AA00-0AA0	SIMATIC S7-400, ADAPTIONS KAPSEL
6ES7478-1AN00-0AA0	SIMATIC M7-400, SPEICHERMODUL
6ES7478-1AN10-0AA0	SIMATIC M7-400, SPEICHERMODUL
6ES7478-1BM10-0AA0	SIMATIC M7-400, SPEICHERMODUL
6ES7478-2AC00-0AC0	SIMATIC M7-400,
6ES7478-2BA00-0AC0	SIMATIC M7-400,
6ES7478-2CA00-0AC0	SIMATIC M7-400,
6ES7486-3AA00-0AB0	SIMATIC M7-400, CPU486-3
6ES7488-3AA00-0AB0	SIMATIC M7-400, CPU488-3
6ES7488-4GY00-0AC0	SIMATIC M7-400, CPU488-4
6ES7488-5FY00-0AC0	SIMATIC M7-400, CPU488-5
6ES7490-0AA00-0AA0	SIMATIC S7-400, ERSATZTEIL
6ES7490-0AB00-0AA0	SIMATIC S7-400, ERSATZTEIL
6ES7490-1AA00-0AA0	SIMATIC S7-400, ERSATZTEIL
6ES7490-1BA00-0AA0	SIMATIC S7/M7, VERBINDUNGSKLEMME
6ES7492-1AL00-0AA0	SIMATIC S7-400, FRONTSTECKER
6ES7492-1BL00-0AA0	SIMATIC S7-400, FRONTSTECKER
6ES7492-1CL00-0AA0	SIMATIC S7-400, FRONTSTECKER
6ES7492-1XL00-0AA0	SIMATIC S7-400, ERSATZTEILSET
6ES7492-2XL00-0AA0	SIMATIC S7-400, FRONTKLAPPE
6ES7612-2QH00-0AB4	SIMATIC WINAC ERSATZTEIL
6ES7613-0CA00-1CA0	SIMATIC C7-613,
6ES7613-1CA00-0AE3	SIMATIC C7-613, KOMPLETTGERAET
6ES7613-1CA01-0AE3	SIMATIC C7-613, KOMPLETTGERAET
6ES7614-1AH00-0AB3	SIMATIC S7, BRANCHEN - CPU 614,
6ES7614-1AH01-0AB3	SIMATIC S7, BRANCHEN - CPU 614,
6ES7614-1AH02-0AB3	SIMATIC S7, BRANCHEN - CPU 614,
6ES7614-1AH03-0AB3	SIMATIC S7, BRANCHEN - CPU 614,
6ES7616-2PG01-0AB4	SIMATIC WINAC PRO LITE SLOT-PLC
6ES7616-2PK01-0AB4	SIMATIC WINAC, ERSATZTEIL
6ES7616-2QL00-0AB4	SIMATIC WINAC ERSATZTEIL
6ES7620-0AA00-3AA0	SIMATIC C7, SCHUTZRAHMEN
6ES7620-0AA00-4AA0	SIMATIC C7-620, SIMULATORBAUGR.
6ES7621-1AD00-0AE3	SIMATIC C7-621, KOMPLETTGERAET
6ES7621-1AD00-6AE3	SIMATIC C7-621, ANSCHALTUNG
6ES7621-1AD01-0AE3	SIMATIC C7-621, KOMPLETTGERAET
6ES7621-1AD02-0AE3	SIMATIC C7-621, KOMPLETTGERAET
6ES7621-6BD00-0AE3	SIMATIC C7-621, KOMPLETTGERAET
6ES7621-6BD01-0AE3	SIMATIC C7-621 ASI, KOMPL.GERAET
6ES7621-6BD02-0AE3	SIMATIC C7-621 ASI, KOMPL.GERAET
6ES7623-1AE00-0AE3	SIMATIC C7-623, KOMPAKTSTATION
6ES7623-1AE00-3AA0	SIMATIC C7, ERSATZTEIL

Order No.	Description
6ES7623-1AE00-6AA0	SIMATIC C7, EIN-/AUSGABEBAUGR.
6ES7623-1AE01-0AE3	SIMATIC C7-623, KOMPAKTSTATION
6ES7623-1AE01-4AA0	SIMATIC C7, STECKERSATZ FUER
6ES7623-1AE01-5AA0	SIMATIC C7,
6ES7623-1CE00-0AE3	SIMATIC C7-623/A,KOMPAKTSTATION
6ES7623-1CE01-0AE3	SIMATIC C7-623/A,KOMPLETTGERAET
6ES7623-1DE01-0AE3	SIMATIC C7-623/P,KOMPLETTGERAET
6ES7623-1SB01-0AC0	SIMATIC C7-623/P,
6ES7624-1AE00-0AE3	SIMATIC C7-624, KOMPAKTSTATION
6ES7624-1AE01-0AE3	SIMATIC C7-624, KOMPAKTSTATION
6ES7624-1DE01-0AE3	SIMATIC C7-624/P,KOMPLETTGERAET
6ES7626-0AA00-0AE3	SIMATIC C7-626, DISPLAY
6ES7626-1AG00-0AE3	SIMATIC C7-626, KOMPLETTGERAET
6ES7626-1AG01-0AE3	SIMATIC C7-626, KOMPLETTGERAET
6ES7626-1AG02-0AE3	SIMATIC C7-626, KOMPLETTGERAET
6ES7626-1CG00-0AE3	SIMATIC C7-626/A,KOMPLETTGERAET
6ES7626-1CG01-0AE3	SIMATIC C7-626/A,KOMPLETTGERAET
6ES7626-1CG02-0AE3	SIMATIC C7-626/A,KOMPLETTGERAET
6ES7626-1DG02-0AE3	SIMATIC C7-626/P,KOMPLETTGERAET
6ES7626-1DG03-0AE3	SIMATIC C7-626/P,KOMPLETTGERAET
6ES7626-1DG04-0AE3	SIMATIC C7-626/P,KOMPLETTGERAET
6ES7626-2AG00-0AE3	SIMATIC C7-626 DP, KOMPL.GERAET
6ES7626-2AG01-0AE3	SIMATIC C7-626 DP, KOMPL.GERAET
6ES7626-2AG02-0AE3	SIMATIC C7-626 DP, KOMPL.GERAET
6ES7626-2CG01-0AE3	SIMATIC C7-626/A DP,KOMP.GERAET
6ES7626-2DG02-0AE3	SIMATIC C7-626/P DP,KOMP.GERAET
6ES7626-2DG03-0AE3	SIMATIC C7-626/P DP,KOMP.GERAET
6ES7626-2DG04-0AE3	SIMATIC C7-626/P DP,KOMP.GERAET
6ES7630-0DA00-0AB0	SIMATIC C7, EIN-/AUSGABEBAUGR.
6ES7633-1DF00-0AE3	SIMATIC C7-633/P,KOMPLETTGERAET
6ES7633-1DF01-0AE3	SIMATIC C7-633/P,KOMPLETTGERAET
6ES7633-1DF02-0AE3	SIMATIC C7-633/P,KOMPLETTGERAET
6ES7633-2BF00-0AE3	SIMATIC C7-633 DP, KOMPL.GERAET
6ES7633-2BF01-0AE3	SIMATIC C7-633 DP, KOMPL.GERAET
6ES7633-2BF02-0AE3	SIMATIC C7-633 DP, KOMPL.GERAET
6ES7633-2BJ01-0AE3	SIMATIC C7-633 DP, KOMPL.GERAET
6ES7633-2BJ02-0AE3	SIMATIC C7-633 DP, KOMPL.GERAET
6ES7634-1DF00-0AE3	SIMATIC C7-634/P,KOMPLETTGERAET
6ES7634-1DF01-0AE3	SIMATIC C7-634/P,KOMPLETTGERAET
6ES7634-1DF02-0AE3	SIMATIC C7-634/P,KOMPLETTGERAET
6ES7634-2BF00-0AE3	SIMATIC C7-634 DP, KOMPL.GERAET
6ES7634-2BF01-0AE3	SIMATIC C7-634 DP, KOMPL.GERAET
6ES7634-2BF02-0AE3	SIMATIC C7-634 DP, KOMPL.GERAET
6ES7635-0AA00-3AA0	SIMATIC C7-613/C7-635,
6ES7635-0AA00-4AA0	SIMATIC C7-613/-635/-636,
6ES7635-0AA00-4BA0	SIMATIC C7-613/-635/-636,
6ES7635-0AA00-6AA0	SIMATIC C7-613/C7-635,
6ES7635-0AA00-6BA0	SIMATIC C7-613/C7-635,
6ES7635-0AA00-6CA0	SIMATIC C7-613/C7-635,
6ES7635-0AA00-6EA0	SIMATIC C7-613/C7-635,
6ES7635-2EB00-0AE3	SIMATIC C7-635 TOUCH,

Order No.	Description
6ES7635-2EB01-0AE3	SIMATIC C7-635 TOUCH,
6ES7635-2EC00-0AE3	SIMATIC C7-635 TASTEN,
6ES7635-2EC01-0AE3	SIMATIC C7-635 TASTEN,
6ES7636-2EC00-0AE3	SIMATIC C7-636 TASTEN,
6ES7654-7HY00-0XA0	SIMATIC S7, BUSMODUL
6ES7678-1RA00-0XB0	SIMATIC WINAC SLOT PSEB,
6ES7700-0AL00-0YA0	SIMATIC UD700, UPDATE DEVICE
6ES7901-0BF00-0AA0	SIMATIC S7, MPI-KABEL
6ES7901-3BF20-0XA0	SIMATIC S7, PC/PPI-KABEL
6ES7901-3BF21-0XA0	SIMATIC S7-200, PC/PPI-KABEL
6ES7901-3CB30-0XA0	SIMATIC S7-200, PC/PPI-KABEL MM
6ES7901-3DB30-0XA0	SIMATIC S7-200,USB/PPI-KABEL MM
6ES7951-0AG00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7951-0FE00-0AA0	SIMATIC S7, MEMORY CARD
6ES7951-0KD00-0AA0	SIMATIC S7, MEMORY CARD 16 KB
6ES7951-0KD80-0AA0	SIMATIC S7, MEMORY CARD
6ES7951-0KE00-0AA0	SIMATIC S7, MEMORY CARD 32KB
6ES7951-0KE80-0AA0	SIMATIC S7, MEMORY CARD
6ES7951-0KF00-0AA0	SIMATIC S7, MEMORY CARD 64 KB
6ES7951-0KF80-0AA0	SIMATIC S7, MEMORY CARD
6ES7951-0KG00-0AA0	SIMATIC S7, MEMORY CARD
6ES7951-0KJ00-0AA0	SIMATIC S7, MEMORY CARD
6ES7951-1AH00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7951-1AJ00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7951-1AK00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7951-1AL00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7951-1KH00-0AA0	SIMATIC S7, MEMORY CARD
6ES7951-1KK00-0AA0	SIMATIC S7, MEMORY CARD
6ES7951-1KL00-0AA0	SIMATIC S7, MEMORY CARD
6ES7951-1KM00-0AA0	SIMATIC S7, MEMORY CARD
6ES7952-0AF00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7952-0KF00-0AA0	SIMATIC S7, MEMORY CARD
6ES7952-0KH00-0AA0	SIMATIC S7, MEMORY CARD
6ES7952-1AH00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7952-1AK00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7952-1AL00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7952-1AM00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7952-1AP00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7952-1AS00-0AA0	SIMATIC S7, RAM MEMORY CARD
6ES7952-1KK00-0AA0	SIMATIC S7, MEMORY CARD
6ES7952-1KL00-0AA0	SIMATIC S7, MEMORY CARD
6ES7952-1KM00-0AA0	SIMATIC S7, MEMORY CARD
6ES7952-1KP00-0AA0	SIMATIC S7, MEMORY CARD
6ES7952-1KS00-0AA0	SIMATIC S7, MEMORY CARD
6ES7952-1KT00-0AA0	SIMATIC S7, MEMORY CARD
6ES7952-1KY00-0AA0	SIMATIC S7, MEMORY CARD
6ES7953-8LF00-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LF10-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LF11-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LG00-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LG10-0AA0	SIMATIC S7, MICRO MEMORY CARD

Order No.	Description
6ES7953-8LG11-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LJ00-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LJ10-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LJ11-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LL00-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LL10-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LL11-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LM00-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LM10-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LM11-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LP10-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7953-8LP11-0AA0	SIMATIC S7, MICRO MEMORY CARD
6ES7955-2AL00-0AA0	SIMATIC S7-400, ARBEITSSPEICHER
6ES7955-2AM00-0AA0	SIMATIC S7-400, ARBEITSSPEICHER
6ES7955-2AM10-0AA0	SIMATIC S7-400H,ARBEITSSPEICHER
6ES7960-1AA00-0XA0	SIMATIC S7-400H,
6ES7960-1AA00-5AA0	SIMATIC S7-400H, SYNC-KABEL LWL
6ES7960-1AA00-5BA0	SIMATIC S7-400H, SYNC-KABEL LWL
6ES7960-1AA00-5KA0	SIMATIC S7-400H, SYNC-KABEL LWL
6ES7960-1AA04-0XA0	SIMATIC S7-400H,
6ES7960-1AA04-5AA0	SIMATIC S7-400H,
6ES7960-1AA04-5BA0	SIMATIC S7-400H,
6ES7960-1AA04-5KA0	SIMATIC S7-400H,
6ES7960-1AB04-0XA0	SIMATIC S7-400H,
6ES7961-1AA00-0AC0	SIMATIC M7,
6ES7961-2AA00-0AC0	SIMATIC M7,
6ES7961-3AA00-0AC0	SIMATIC M7,
6ES7962-1BA01-0AC0	SIMATIC M7,
6ES7962-3AA00-0AC0	SIMATIC M7,
6ES7962-4AA00-0AC0	SIMATIC M7,
6ES7963-1AA00-0AA0	SIMATIC S7-400,
6ES7963-2AA00-0AA0	SIMATIC S7-400,
6ES7963-3AA00-0AA0	SIMATIC S7-400,
6ES7964-2AA00-0AB0	SIMATIC M7-400,
6ES7964-2AA01-0AB0	SIMATIC S7, IF964-DP
6ES7964-2AA04-0AB0	SIMATIC S7, IF964-DP
6ES7968-0AA00-0AA0	SIMATIC M7, ZUBEHOER
6ES7971-0AB00	SIMATIC S7, Pufferbatterie 3,6V / 1,9Ah
6ES7971-0BA00	SIMATIC S7-400, PUFFERBATTERIE
6ES7971-1AA00-0AA0	SIMATIC S7, PUFFERBATTERIE (LI)
6ES7971-2BA00-0AA0	SIMATIC WINAC, PUFFERBATTERIE
6ES7971-5BB00-0AA0	SIMATIC S7-300, AKKU
6ES7972-0AA00-0XA0	SIMATIC S7, RS485 REPEATER
6ES7972-0AA01-0XA0	SIMATIC DP, RS485 REPEATER
6ES7972-0AB00-0XA0	SIMATIC S7, DIAGNOSE-REPEATER
6ES7972-0AB01-0XA0	SIMATIC S7, DIAGNOSE-REPEATER
6ES7972-0AC80-0XA0	SIMATIC DP, DEZENTR. PERIPHERIE
6ES7972-0BA11-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7972-0BA12-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7972-0BA30-0XA0	SIMATIC DP, BUSANSCHLUSS-
6ES7972-0BA40-0XA0	SIMATIC DP, ANSCHLUSSSTECKER

Order No.	Description
6ES7972-0BA41-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7972-0BA50-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7972-0BA60-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7972-0BB11-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7972-0BB12-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7972-0BB40-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7972-0BB41-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7972-0BB50-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7972-0BB60-0XA0	SIMATIC DP, ANSCHLUSSSTECKER
6ES7972-0CA11-0XA0	SIMATIC S7, HMI ADAPTER V5
6ES7972-0CA32-0XA0	SIMATIC S7, TS ADAPTER V5
6ES7972-0CA33-0XA0	SIMATIC S7, TS ADAPTER V5.1
6ES7972-0CA34-0XA0	SIMATIC S7, TS-ADAPTER 5.2
6ES7972-0CB35-0XA0	SIMATIC S7, TS-ADAPTER II
6ES7972-0CC35-0XA0	SIMATIC S7, TS-ADAPTER II ISDN
6ES7972-0DA00-0AA0	SIMATIC DP, RS485 ABSCHLUSS-
6ES7972-0DA30-0XA0	SIMATIC DP, BUSANSCHLUSSSTECKER
6ES7972-4AA00-0XA0	SIMATIC DP, POWER RAIL BOOSTER
6ES7972-4AA01-0XA0	SIMATIC DP, POWER RAIL BOOSTER
6ES7973-1HD00-0AA0	SIMATIC S7, SICHERUNGSSATZ
6ES7973-1HD10-0AA0	SIMATIC S7-400, ERSATZTEIL
6ES7974-0AA00-0AA0	SIMATIC S7, MESSBEREICHSMODULE
6EV2031-4EC00	SIMATIC S5, STROMVERSORGUNG
6EV2230-4DK	SIMADYN-C-NETZGER. +-15V
6EW1000-7AA	SIMATIC S5, PUFFERBATTERIE
6EW1160-5AF	SIMATIC S5, STROMVERSORGUNG
6GK1100-0AA00	SIMATIC NET, SIBUKO-PAKET 1
6GK1100-0AB00	SIMATIC NET, SIBUKO-PAKET 2
6GK1100-0AF00	SINEC H1FO BUSKOPPLER
6GK1100-0AG00	SINEC H1FO BUSKOPPLER EINSCHUB
6GK1100-0AG01	SINEC H1FO BUSKOPPLER EINSCHUB
6GK1100-0AH00	SINEC H1FO ZWEIKANALEINSCH. ZUM
6GK1100-0AH01	SINEC H1FO ZWEIKANALEINSCH. ODM
6GK1100-0AJ00	SIMATIC NET, SIBUKO-PAKET 6
6GK1100-0BA00	SIMATIC NET, TPTR
6GK1100-2AB00	SIMATIC NET, IE OMC TP11
6GK1100-2AC00	SIMATIC NET, IE OMC TP11-LD
6GK1101-0AA01	SINEC H1FO AKTIVER STERNKOPPLER
6GK1101-0AB01	SINEC H1FO AKTIVER STERNKOPPLER
6GK1102-0AA00	SINEC H1 SSV 102 A
6GK1102-0AB00	SINEC H1 SSV 102 B
6GK1102-0AC00	SIMATIC NET, SSV 102
6GK1102-4AA00	SIMATIC NET, OLM F. INDUSTRIAL
6GK1102-5AA00	SIMATIC NET, ELM F. INDUSTRIAL
6GK1102-6AA00	SIMATIC NET, ELS TP40
6GK1102-6AB00	SIMATIC NET, ELS TP40M
6GK1102-7AA00	SIMATIC NET, ELS TP80
6GK1104-0AA00	SIMATIC NET, SSV 104
6GK1105-0AA00	SIMATIC NET, IND.ETHERNET OSM
6GK1105-1AA00	SIMATIC NET, IND. ETHERNET ORM
6GK1105-2AA00	SIMATIC NET, OSM ITP62

Order No.	Description
6GK1105-2AA10	SIMATIC NET, OSM ITP62
6GK1105-2AB00	SIMATIC NET, OSM TP62
6GK1105-2AB10	SIMATIC NET, OSM TP62
6GK1105-2AC00	SIMATIC NET, OSM ITP62-LD
6GK1105-2AC10	SIMATIC NET, OSM ITP62-LD
6GK1105-2AD00	SIMATIC NET, OSM ITP53
6GK1105-2AD10	SIMATIC NET, OSM ITP53
6GK1105-2AE00	SIMATIC NET, OSM TP22
6GK1105-3AA00	SIMATIC NET, ESM ITP80
6GK1105-3AA10	SIMATIC NET, ESM ITP80
6GK1105-3AB00	SIMATIC NET, ESM TP80
6GK1105-3AB10	SIMATIC NET, ESM TP80
6GK1105-3AC00	SIMATIC NET, ESM TP40
6GK1105-4AA00	SIMATIC NET, OSM BC08
6GK1110-0AA00	SIMATIC NET, REPEATER FUER
6GK1110-1AA00	SIMATIC NET, IE RADIO LINK
6GK1140-0AA00	SINEC SK132 ANSCHALTMODUL ETC
6GK1140-0AB00	SK132 ANSCHALTMODUL ETC 216
6GK1140-0AC00	SINEC KONZENTRATOR 132
6GK1140-0BA00	CP 1400 OHNE SOFTWARE
6GK1140-1NA00	SIMATIC NET, CP 1401
6GK1141-0AA00	SINEC KOMMUNIKATIONSPROZESSOR
6GK1141-1AA00	SIMATIC NET, CP 1411
6GK1143-0AA01	SINEC H1 ANSCHALTUNG CP 143 TF
6GK1143-0AB01	SINEC H1 ANSCHALTUNG CP 143 TF
6GK1143-0TA02	SINEC CP 1430 TF
6GK1143-0TB01	SINEC CP 1430 TF
6GK1147-0AA10	SIMATIC NET, CP1470 (A1)
6GK1147-1AA10	SINEC CP1471 (A1)
6GK1147-3MA00	SINEC CP 1473 MAP
6GK1147-5AA01	SINEC CP1475 TF
6GK1147-5MA00	SINEC CP 1475 MAP
6GK1147-6MA01	SINEC CP 1476 MAP
6GK1151-1AA00	SIMATIC NET, CP 1511
6GK1151-2AA00	SIMATIC NET, IE, CP 1512 PC
6GK1151-5AA00	SIMATIC NET,IE, CP 1515 PCMCIA
6GK1161-2AA00	SIMATIC NET,IE,CP1612 PCI-KARTE
6GK1161-3AA00	SIMATIC NET, IE, CP 1613
6GK1210-0SA00	SIMATIC NET, REPEATER
6GK1210-1SA00	SIMATIC NET, EXTENDER
6GK1241-3SA00	SIMATIC NET, CP 2413
6GK1243-0SA10	SINEC CP 2430
6GK1243-0SA20	SINEC CP 2430
6GK1243-3SA00	SINEC CP 2433
6GK1400-0AA00	SINEC BRIDGE 400 ZUR KOPPLUNG
6GK1411-5AA00	SIMATIC NET, IE/PB LINK
6GK1411-5AA20	SIMATIC NET, IE/PB LINK
6GK1415-0AA00	SIMATIC NET, DP/EIB LINK
6GK1415-0AA01	SIMATIC NET, DP/EIB LINK
6GK1415-2AA00	SIMATIC NET, DP/AS-INTERFACE
6GK1415-2AA01	SIMATIC NET, DP/AS-INTERFACE

Order No.	Description
6GK1500-0AA00	SIMATIC NET, BUSTERMINAL RS 485
6GK1500-0AA10	SIMATIC NET, BUSTERMINAL 12M
6GK1500-0AB00	SIMATIC NET, BUSTERMINAL RS 485
6GK1500-0DA00	SIMATIC NET, BUSTERMINAL RS 485
6GK1500-0EA02	SIMATIC NET, PB FC RS 485 PLUG
6GK1500-0FC00	SIMATIC NET, PB FC RS 485 PLUG
6GK1500-1AA00	SIMATIC NET, OPT.BUSTERMINAL PF
6GK1500-1AB00	SIMATIC NET, OPT.BUSTERMINAL SF
6GK1500-3AA00	SIMATIC NET, PROFIBUS OBT
6GK1501-0AA00	SIMATIC NET, AS 501 A
6GK1501-0AB00	SIMATIC NET, AS 501 B
6GK1501-1AA00	SIMATIC NET, EINKANALEINSCHUB
6GK1501-1AB00	SIMATIC NET, EINKANALEINSCHUB
6GK1502-1AA00	SIMATIC NET,OLP F.PROFIBUS
6GK1502-2CA00	SIMATIC NET, PB OLM/P11 V3
6GK1502-2CA10	SIMATIC NET, PB OLM/P11 V3.1
6GK1502-2CB00	SIMATIC NET, PB OLM/G11 V3
6GK1502-2CB10	SIMATIC NET, PB OLM/G11 V3.1
6GK1502-2CC00	SIMATIC NET, PB OLM/G11-1300 V3
6GK1502-2CC10	SIMATIC NET,PB OLM/G11-1300V3.1
6GK1502-3AA10	SIMATIC NET, OLM/P3 (A2)
6GK1502-3AB10	SIMATIC NET, OLM/S3 (A2)
6GK1502-3AC10	SIMATIC NET, OLM/S3-1300
6GK1502-3BA00	SIMATIC NET, OLM12M F. PROFIBUS
6GK1502-3CA00	SIMATIC NET, PB OLM/P12 V3
6GK1502-3CA10	SIMATIC NET, PB OLM/P12 V3.1
6GK1502-3CB00	SIMATIC NET, PROFIBUS OLM/G12
6GK1502-3CB10	SIMATIC NET, PROFIBUS OLM/G12
6GK1502-3CC00	SIMATIC NET, PB OLM/G12-1300 V3
6GK1502-3CC10	SIMATIC NET, PB OLM/G12-1300
6GK1502-3CD00	SIMATIC NET, PB OLM/G12-EEC
6GK1502-3CD10	SIMATIC NET, PB OLM/G12-EEC
6GK1502-4AA10	SIMATIC NET, OLM/P4 (A2)
6GK1502-4AB10	SIMATIC NET, OLM/S4 (A2)
6GK1502-4AC10	SIMATIC NET, OLM/S4-1300
6GK1503-0AA00	SIMATIC NET, PROFIBUS ILM
6GK1510-0AC00	SIMATIC NET,REPEATER RS485 IP20
6GK1510-0AD00	SIMATIC NET,REPEATER RS485 IP65
6GK1510-1AA00	SINEC L2 REPEATERADAPTER SF
6GK1510-1AB00	SINEC L2 REPEATERREDUNDANZ-
6GK1541-1AA00	SIMATIC NET, CP 5411
6GK1541-2BA00	SIMATIC NET, PB, CP 5412 (A2)
6GK1543-0AA00	SINEC CP5430
6GK1543-0AA02	SINEC CP5430 TF (A2)
6GK1543-1AA01	SINEC CP5431 FMS / DP
6GK1548-0AA00	SINEC CP5480 (A0)
6GK1548-0BA00	SIMATIC NET, CP 5480 FDL
6GK1548-0DA10	CP 5480-DP MASTER
6GK1548-0FA00	SIMATIC NET, CP 5480 FMS
6GK1551-1AA00	SIMATIC NET, PB, CP 5511
6GK1551-2AA00	SIMATIC NET, PB, CP 5512

Order No.	Description
6GK1561-1AA00	SIMATIC NET, PB, CP 5611
6GK1561-3AA00	SIMATIC NET, CP 5613, PCI-KARTE
6GK1561-3AA01	SIMATIC NET, CP 5613A2, PCI-KARTE
6GK1561-3FA00	SIMATIC NET, CP5613FO, PCI-KARTE
6GK1561-4AA00	SIMATIC NET, CP 5614, PCI-KARTE
6GK1561-4AA01	SIMATIC NET, CP 5614A2, PCI-KARTE
6GK1561-4FA00	SIMATIC NET, CP5614FO, PCI-KARTE
6GK1610-0TA00	SIMATIC NET, MOBIC T8, DEUTSCH
6GK1610-0TA01	SIMATIC NET, MOBIC T8, ENGLISCH
6GK1611-0TA01-0AX0	SIMATIC NET, MOBIC T8 D,E,F,S,I
6GK1611-0TA01-1BV0	SIMATIC NET, MOBIC T8 CHIN.V1.1C
6GK1611-0TA01-1DV0	SIMATIC NET, MOBIC T8 CHIN.V1.2
6GK1751-5AA00	SIMATIC NET, IWLAN, CP 7515
6GK1900-0AB00	SIMATIC NET, CONFIGURATION PLUG
6GK1900-0HB00-0AC0	SIMATIC NET, BFOC PLUG PCF
6GK1900-0HL00-0AA0	SIMATIC NET, TERMINATION KIT
6GK1900-0KB00-0AC0	SIMATIC NET, SIMPLEX PLUG PCF
6GK1900-0KL00-0AA0	SIMATIC NET, TERMINATION KIT
6GK1901-0AA00-0AA0	SIMATIC NET, BUSKOPPLER
6GK1901-0AA00-0AC0	SIMATIC NET, BUSKOPPLER MIT 2SS
6GK1901-1BB10-2AA0	SIMATIC NET IE FC RJ45 PLUG 180
6GK1901-1BB10-2AB0	SIMATIC NET IE FC RJ45 PLUG 180
6GK1901-1BB10-2AE0	SIMATIC NET IE FC RJ45 PLUG 180
6GK1901-1BB20-2AA0	SIMATIC NET IE FC RJ45 PLUG 90
6GK1901-1BB20-2AB0	SIMATIC NET IE FC RJ45 PLUG 90
6GK1901-1BB20-2AE0	SIMATIC NET IE FC RJ45 PLUG 90
6GK1901-1FC00-0AA0	SIMATIC NET, IE FC OUTLET RJ45
6GK1901-2AA00-0AA0	SINEC ANZEIGEELEMENT: LED-AN-
6GK1901-4AA00-0AA0	SINEC H1FO KOLLISIONSERKENN-
6GK1901-8AB00-0AA0	SINEC UHRZEITMODUL S5
6GK1901-8AB01-0AA0	SINEC UHRZEITMODUL S5 FUER
6GK1906-1BA00	SIMATIC NET, MOBIC AKKU
6GK1906-1BB00	SIMATIC NET, MOBIC WECHSELAKKU
6GK1906-1CA02	SIMATIC NET, MOBIC NETZKABEL UK
6GK1906-1CB00	SIMATIC NET, MOBIC NETZTEIL
6GK1906-1CC00	SIMATIC NET, MOBIC LADENETZTEIL
6GK1921-0AA00-0AA0	SINEC MULTITESTSTATION
6GK1921-0AA01-0AA0	SIMATIC NET, UHRZEITSENDER
6GK5104-2BB00-2AA3	SIMATIC NET, SCALANCE X104-2,
6GK5106-1BB00-2AA3	SIMATIC NET, SCALANCE X106-1,
6GK5108-0BA00-2AA3	SIMATIC NET, SCALANCE X108,
6GK5204-2BB00-2AA3	SIMATIC NET, SCALANCE X204-2,
6GK5206-1BB00-2AA3	SIMATIC NET, SCALANCE X206-1,
6GK5208-0BA00-2AA3	SIMATIC NET, SCALANCE X208,
6GK5208-0CA00-2AA6	SIMATIC NET, SCALANCE X208PRO,
6GK5414-3FC00-2AA2	SIMATIC NET, SCALANCE X414-3E,
6GK5490-0AA00-0AA2	SIMATIC NET, SCALANCE X-400
6GK5491-2AB00-8AA2	SIMATIC NET,
6GK5491-2AC00-8AA2	SIMATIC NET,
6GK5492-2AL00-8AA2	SIMATIC NET,
6GK5492-2AM00-8AA2	SIMATIC NET,

Order No.	Description
6GK5495-8BA00-8AA2	SIMATIC NET,
6GK5496-4MA00-8AA2	SIMATIC NET,
6GK5498-0AA00-0AA0	SIMATIC NET, SCALANCE X-400
6GK5498-1AA00-0AA0	SIMATIC NET, SCALANCE X-400
6GK5744-1ST00-2AA6	SIMATIC NET, IWLAN ETHERNET
6GK5744-1ST00-2AB6	SIMATIC NET, IWLAN ETHERNET
6GK5788-1ST00-2AA6	SIMATIC NET, IWLAN ACCESS POINT
6GK5788-1ST00-2AB6	SIMATIC NET, IWLAN ACCESS POINT
6GK5788-2ST00-2AA6	SIMATIC NET, IWLAN DUAL ACCESS
6GK5788-2ST00-2AB6	SIMATIC NET, IWLAN DUAL ACCESS
6GK5791-1PS00-0AA6	SIMATIC NET, POWER SUPPLY
6GK5793-8DR00-0AB6	SIMATIC NET, IWLAN ANTENNA ANT
6GK5795-4MR00-0AA6	SIMATIC NET, IWLAN ANTENNA ANT
6GK5795-6MR00-0AA6	SIMATIC NET, IWLAN ANTENNA ANT
6GK5798-1LP00-0AA6	SIMATIC NET, IWLAN LIGHTNING
6GK7142-2AH00-0XA0	SIMATIC NET, CP 142-2
6GK7242-2AX00-0XA0	SIMATIC NET, CP 242-2
6GK7242-8DP00-0XA0	SIMATIC NET, CP 242-8
6GK7243-1EX00-0XE0	SIMATIC NET, CP 243-1
6GK7243-1GX00-0XE0	SIMATIC NET, CP 243-1IT
6GK7243-2AX01-0XA0	SIMATIC NET, CP 243-2
6GK7342-2AH01-0XA0	SIMATIC NET, CP 342-2
6GK7342-5DA01-0XE0	SIMATIC NET, CP 342-5
6GK7342-5DA02-0XE0	SIMATIC NET, CP 342-5
6GK7342-5DF00-0XE0	SIMATIC NET, CP 342-5 FO
6GK7343-1BA00-0XE0	SIMATIC NET, CP 343-1
6GK7343-1CX00-0XE0	SIMATIC NET, CP 343-1 LEAN
6GK7343-1EX00-0XE0	SIMATIC NET, CP 343-1 TCP
6GK7343-1EX10-0XE0	SIMATIC NET, CP 343-1
6GK7343-1EX11-0XE0	SIMATIC NET, CP 343-1
6GK7343-1EX20-0XE0	SIMATIC NET, CP 343-1
6GK7343-1GX00-0XE0	SIMATIC NET, CP 343-1 IT
6GK7343-1GX11-0XE0	SIMATIC NET, CP 343-1 IT
6GK7343-1GX20-0XE0	SIMATIC NET, CP 343-1IT
6GK7343-1HX00-0XE0	SIMATIC NET, CP 343-1 PN
6GK7343-2AH00-0XA0	SIMATIC NET, CP 343-2
6GK7343-2AH10-0XA0	SIMATIC NET, CP 343-2 P
6GK7343-5FA00-0XE0	SIMATIC NET, CP 343-5
6GK7343-5FA01-0XE0	SIMATIC NET, CP 343-5
6GK7443-1EX10-0XE0	SIMATIC NET, CP 443-1
6GK7443-1EX11-0XE0	SIMATIC NET, CP 443-1
6GK7443-1EX40-0XE0	SIMATIC NET, CP 443-1 ADVANCED
6GK7443-1GX10-0XE0	SIMATIC NET, CP 443-1 IT
6GK7443-1GX11-0XE0	SIMATIC NET, CP 443-1 IT
6GK7443-5DX02-0XE0	SIMATIC NET, CP 443-5 EXTENDED
6GK7443-5DX03-0XE0	SIMATIC NET, CP 443-5 EXTENDED
6GK7443-5DX04-0XE0	SIMATIC NET, CP 443-5 EXTENDED
6GK7443-5FX01-0XE0	SIMATIC NET, CP 443-5 BASIC
6GK7443-5FX02-0XE0	SIMATIC NET, CP 443-5 BASIC